

# PLEASE READ THE FOLLOWING PRIOR TO OPERATION OF THIS EQUIPMENT!

The following are basic safety precautions to understand when operating this Terex tractor. It is **NOT** intended to be a complete list of safety precautions. Please review the Operator Manual prior to operation. If one is not on the machine, contact All Star Rents and we will supply one to you.

## Basic Operation & Safety Requirements





This symbol means: **Attention! Be Alert! Your safety is involved!** The safety alert symbols found on decals and in the Operator Manual alert you to potential safety hazards. Obey all safety messages with this symbol to avoid possible injury or death.

Other similar symbols: **⚠️ WARNING** **⚠️ DANGER** **⚠️ CAUTION**



Refer to the Operator Manual for any operational or safety questions you may have. Contact All Star Rents prior to operation if one is not located on the machine. If you are new to operating this machine you should practice in a safe area and refer to Operator Manual for instructions



Use caution when operating on uneven terrain. Avoid any slopes where the machine could fall over. Always put the heaviest end of the machine on the uphill side whether going up or down a slope. Avoid side hill work (downhill to left or right as opposed to in front or behind), as this is the most common cause of overturning. Understand that “soft” ground conditions can allow tractor to shift and tilt. **Keep the bucket or any implement on the tractor at the lowest possible position!** Any damage as a result of a machine tipping off either track is not covered by the Equipment Protection Plan.



Always fasten your seat belt and follow other precautions that keep you inside the ROPS (protection cage). Failing to do so could allow ejection from this protective area result in death or injury including the tractor crushing you.



**NEVER** allow riders anywhere on the machine!



Be aware of others around you. Maintain a safe distance from bystanders at all times. Always look in the direction of travel. Buckets and other implement present a crushing and impact injury danger. Remain in ROPS area while machine is running.



Contact All Star Rents immediately if you have any problems with the machine. **DO NOT** attempt to repair, upright or start the machine if it has tipped over. Doing so could result in further injury or damage to the equipment. Call 911 first if serious injury as occurred while operating the tractor.

## All Star Rents Toll Free: 866-ALL STAR